

ÜBERSICHT DER BEFESTIGUNGSTECHNIK RADIK

			Modell und Typ																
Typ der Konsole	Höhe H [mm]	Bestellnummer	KLASIK / PLAN (LINE) KLASIK KLASIK - Z						VK / PLAN (LINE) VK / VK - Z VKL / PLAN (LINE) VKL						KLASIK-R				
			10	11	20	21	22	33	10	11	20	21	22	33	20	21	22	33	
Wandkonsole einfach	300 ÷ 900	Z-U320		●	●	●	●	●		●	●	●	●	●	●	●	●	●	●
Wandkonsole einfach - abgewinkelt	300 ÷ 900	Z-U300	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Doppelwandkonsole	300	Z-U562	●	●	●	●	●	●		●	●	●	●	●					
	400	Z-U563	●	●	●	●	●	●		●	●	●	●	●					
	500	Z-U564	●	●	●	●	●	●		●	●	●	●	●					
	600	Z-U565	●	●	●	●	●	●		●	●	●	●	●					
	700	Z-U567	●	●	●	●	●	●		●	●	●	●	●					
	900	Z-U566	●	●	●	●	●	●		●	●	●	●	●					
Doppelwandkonsole MB	300	Z-U521	●	●	●	●	●	●		●	●	●	●	●					
	400	Z-U522	●	●	●	●	●	●		●	●	●	●	●					
	500	Z-U523	●	●	●	●	●	●		●	●	●	●	●					
	600	Z-U524	●	●	●	●	●	●		●	●	●	●	●					
	700	Z-U525	●	●	●	●	●	●		●	●	●	●	●					
	900	Z-U526	●	●	●	●	●	●		●	●	●	●	●					
Kompaktkonsole	300	Z-U571	●	●	●	●	●	●		●	●	●	●	●					
	400	Z-U572	●	●	●	●	●	●		●	●	●	●	●					
	500	Z-U573	●	●	●	●	●	●		●	●	●	●	●					
	600	Z-U574	●	●	●	●	●	●		●	●	●	●	●					
	700	Z-U577	●	●	●	●	●	●		●	●	●	●	●					
	900	Z-U575	●	●	●	●	●	●		●	●	●	●	●					
Kompaktkonsole plus	300	Z-U631			●	●	●	●			●	●	●	●					
	400	Z-U632			●	●	●	●			●	●	●	●					
	500	Z-U633			●	●	●	●			●	●	●	●					
	600	Z-U634			●	●	●	●			●	●	●	●					
	700	Z-U635			●	●	●	●			●	●	●	●					
	900	Z-U636			●	●	●	●			●	●	●	●					
Kompaktkonsole P2	300	Z-U531			●	●	●	●			●	●	●	●					
	400	Z-U532			●	●	●	●			●	●	●	●					
	500	Z-U533			●	●	●	●			●	●	●	●					
	600	Z-U534			●	●	●	●			●	●	●	●					
	700	Z-U535			●	●	●	●			●	●	●	●					
	900	Z-U536			●	●	●	●			●	●	●	●					
Geteilte Konsole plus	200 ÷ 900	Z-U556 Z-U557			●	●	●	●			●	●	●	●					
Geteilte Konsole VERTIKAL	500 ÷ 2000	Z-U558	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Äußere Standkonsole - Set	300 ÷ 900	Z-U210	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Äußere Standkonsole - Stützprofil	300	Z-U220	●	●	●	●	●	●	●	●	●	●	●	●					
	400	Z-U230	●	●	●	●	●	●	●	●	●	●	●	●					
	500	Z-U240	●	●	●	●	●	●	●	●	●	●	●	●					
	600 (554*)	Z-U250	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
	700	Z-U255	●	●	●	●	●	●	●	●	●	●	●	●					
	900	Z-U260	●	●	●	●	●	●	●	●	●	●	●	●					
Standkonsole RADIK Typ 22 und 33	200 ÷ 600	Z-U403					● ¹⁾	● ¹⁾					● ¹⁾	● ¹⁾			● ¹⁾	● ¹⁾	
Innere Standkonsole - Universal	300 ÷ 900	Z-U331		●	●	●	●	●		●	●	●	●	●	●	●	●	●	
Standkonsole für die Typen 22, 33	200 ÷ 900	Z-U400					●	●					●	●			●	●	
Standkonsole W RADIK Typ 22, 33	200 ÷ 900	Z-U392					●	●					●	●			●	●	
Standkonsole für die Typen 20, 21	200 ÷ 900	Z-U390			●	●					●	●			●	●			
Standkonsole W RADIK Typ 20, 21	200 ÷ 900	Z-U391			●	●					●	●			●	●			
Anbohrkonsole 15/120	300 ÷ 900	Z-U140		●	●	●	●	●		●	●	●	●	●	●	●	●	●	
Anbohrkonsole 15/100/70	300 ÷ 900	Z-U141	●						●										
Anbohrkonsole 18/120	300 ÷ 900	Z-U144	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Anbohrkonsole 18/110/100	300 ÷ 900	Z-U290	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Heizkörper mit angeschweißten Laschen			J	J	J	J	J	J	J	J	J	J	J	J	J	J	J	J	

Legende:



● Kann benutzt werden
○ Kann nicht benutzt werden



A ja
N nein

* gilt für RADIK KLASIK - R.

¹⁾ kann nicht für PLAN- und LINE- Ausführung verwendet werden

